



CONCRETE REPAIR AND PROTECTION WITH VANDEX CRS

Patch repair work:



With carbonation barrier:



Application Instructions

Patch repair work:

- 1 Cut back all protrusions to sound concrete, chisel out all damaged sections.
- 2 Apply VANDEX CORROSION PROTECTION M in two coats onto the cleaned reinforcement bars.
- 3 Reprofile the cavities with VANDEX CRS REPAIR MORTAR 05.
- 4 Apply VANDEX CRS LEVELLING COMPOUND LC as skimming coat.

With carbonation barrier:

- 1 Remove all protrusions, cut back to sound concrete, chisel out all damaged sections.
- 2 Apply VANDEX CORROSION PROTECTION M in two coats onto the cleaned reinforcement bars.
- 3 Reprofile the cavities with VANDEX CRS REPAIR MORTAR 05.
- 4 Apply two coats of VANDEX CEMELAST.

Remark:

- Substrate adhesion strength > 1.5 N/mm²

For further technical details and consumptions refer to technical data sheet or consult a technical Vandex representative.

The information contained herein is based on our long-term experience and the best of our knowledge. We can, however, make no guarantee since for a successful outcome, all circumstances in an individual case must be taken into consideration. Indications of quantities required are only averages which in certain cases might be greater.